

How to Apply Iron-On Transfers with Economy Rhinestones



Remove protective plastic backing from transfer.



Place transfer motif on garment or fabric. Place a press cloth or light fabric over the motif if desired



Make certain the temperature and pressure are appropriate (see chart below)



After applying the transfer once, remove sticky film and discard.



Reapply heat again using same temperature, pressure and press cloth



The transfer should now be permanently sealed onto your fabric. when applied properly, it is washable and drycleanable.

Fabric Temperature & Pressure Chart

FINE FABRICS Sill, Polysilk, Lycra	HEAVY FABRICS Jersey, Fleece, Denim
<ul style="list-style-type: none"> ● Temperature : 325-340F ● Pressure: Light(25-35 lbs) ● Time : 7-10 seconds 	<ul style="list-style-type: none"> ● Temperature : 350F ● Pressure: Light to midium (30-40 lbs) ● Time : 10-12 seconds
<ul style="list-style-type: none"> ● Remove Clear film ● Reapply heat for additional 7-10 seconds 	<ul style="list-style-type: none"> ● Remove Clear film ● Reapply heat for additional 10-12 seconds

We reccomed using a protective pad between layers of fabric to prevent adhesive from gluing the fabric together. Pre-test dark colors or non-reactive dyed fabrics for color change from heat.